



CNC Pit Setup

SLQ Wiki Fabrication Lab 2026/04/13 04:24

CNC Pit Setup

OH&S dictates that the CNC Pit needs to remain tidy. For some time there will be weekly inductions (5 participants plus facilitator) and open lab access (min 2 people)

To achieve this we will have a specific list of furniture and equipment stored there. Anything else needs to be removed be the machine is used.

Tools

- Battery drill and charger
- Phillips head Driver bit
- Drill bits
- Screws and washers (well labeled so bed is never punched with longer screws)
- Mallet
- Water spray
- Chuck Wrench 1
- Chuck wrench 2
- Tape measure
- Veneer calliper
- Multi Cam Manual
- Tooling/ collets
- Tarp

Stationary

- Markers (sharpie)
- Pencil
- Whiteboard markers
- Biro
- Clipboards x 6
- Broom

Cleaning/Maintenance

- Spray and Wipe
- Supply of Chux
- WD40
- Steel Wool

PPE

- Gloves (for changing tool and manual handling) x 6 pairs (C)
- Eyes Protection **Clean** x 6 pairs (C)

- Container Eyes Protection **Worn** (C)
- Disposable Hearing protection(C)
- Hearing protection (Muff type) (C)
- Dust masks disposable (C)

Furniture

- Whiteboard
- 6x stools
- Bin (no offcuts)
- Computer bench
- Bookshelves

Signage

(even if these are printouts initially)

- Operator only inside line when machine is cutting
 - Line
 - Eye and hearing protection to be worn when machine is in operation
 - Cut settings
 - Right tool for the job
-
- ***(C)**** A Stock of accountable consumables will be kept in the consumables store and will be stocktaked weekly.
 - See Stock Control for procedures around these items.