

858D+ Hot Air Reflow Station



This is a clone of the ATTEN 858D+.

Recommended Temperatures

- Heat shrink: 150 °C
- Solder: 350 °C

NOTE: These stations have a 'cool down' function that keeps the fan running until the head is below 100°C to protect the elements even when back in it's holder.

It will turn off automatically after a short amount of time.

Helpful links

<https://learn.sparkfun.com/tutorials/how-to-use-a-hot-air-rework-station/all>

User manual

hot_air_gun_858_series_.pdf

[Atten AT858D+ Hot air station](#)