

Tabs & Function Keys

SLQ Wiki Fabrication Lab 2025/07/10 08:23

Tabs & Function Keys

TABS

Tab 1 Job Mode

Tab 2 Position and Jog Mode

Tab 3 Speed Mode

Tab 4 Spindle RPM Mode

Tab 5 Origin Mode

Tab 6 Tooling Mode

Tab 7 Function

General Functions

F1 - A2MC Properties

F2 - Job Verify aqnd Size

F3 - Operator Console Setup

F4 -

XY Operating Functions

Z Origin and Tool Length Origin Functions

Tooling Functions

Productivity Functions

System Control Functions

Tool Path Functions

Multicam Functions

A2MC Setup Functions

Diagnostic Functions

Factory Functions

Other Functions