


ACTIVITY 4 - IDENTIFY 3D PRINTER COMPONENTS

Front Side



COMPONENTS

Back Door

Handle

Magnetic Top Lids

Front Door

LCD Touch Screen

Initialisation Button