



# Up Mini

SLQ Wiki Fabrication Lab 2024/10/03 10:50

# Up Mini

The Up! Mini is a consumer desktop 3D printer, The Edge has four Up! minis available for public use.

## Inductions

### Maintenance

Daily Maintenance:

- Snip off 50mm filament just above intake, withdraw this and extrude freshly snipped end of filament
- Check filament remaining on the spool.

Weekly Maintenance:

- Swap nozzle for nozzle that has been left in acetone for the past week.
- Calibrate Bed Height
- Test Print
- Brush out any accumulated dust and filament below the bed of the machine.

### Some notes on Filament

For some time the edge has had preferred brands of filament - Up brand and Zortrax Brand ABS

These brands have been successfully test in our machine and produce consistent results. The use of other brands of abs is to be avoided to ensure these publically bookable assets remain accessible.

### Repairs to Up Mini 1

Some repairs are being attempted on the retired Up mini 1. This includes fitting an after market "smoothie board" sourced from ebay. Instructions for this board are attached below

[up\\_cpu\\_manual.pdf](#)

### Instructions and Training Materials

[3d\\_printer\\_presentation.pdf](#)

[3d\\_printer\\_printed\\_induction.pdf](#)

[3dprintingdioramalessonplan.pdf](#)

[3dprintingtinkercadlessonplankeyring.pdf](#)

## Manual

[up-mini-3d-printer-manual.pdf](#)

<http://3dprintingsystems.com/up-mini-3d-printer-platform-calibration/>